



DINAN

DI93-0938 HANDLING KIT; A90/A91

INSTALLATION NOTES

Thank you for purchasing a Dinan Handling Kit. We have spent many hours developing this kit to assure that you will receive maximum performance and durability with minimum difficulty in installation. Please take the time to read these instructions and contact us if you have any difficulties during the installation.

This kit is intended to be used with a companion Dinan Spring Set, p/n DI100-0938. This kit contains:

- (4) Bumpstops *

Please include these items when installing the Dinan spring set.

* Dinan's bumpstops may include a plastic or rubber protective boot. Please remove the Dinan boot and reuse the OE boot whenever possible.

Alignment:

- An alignment is required after installation.
- Set tire pressures to factory recommended values.
- All Dinan suspension alignments are done with full fuel tanks and no weight inside the vehicle.
- Specifications are as follows:

FRONT:	Setting	Tolerance
Camber	-2.0°	± 0.42°
Caster	7.5°	± 0.5°
Total Toe	0.27°	± 0.07°
REAR:		
Camber	-2.0°	± 0.08°
Total Toe	0.23°	± 0.07°

If you encounter any difficulties during the installation, or if these instructions are not clear to you, please call Dinan's Technical Support Staff @ (800) 341-5480.

Happy Motoring!