



CARBON REAR SPOILER INSTALLATION INSTRUCTIONS

PART NUMBER D980-0024, -0027, -0028

APPLICATIONS:
2017-18 M2
2019 M2 Competition
2015-19 M3, M4

PARTS LIST

| Qty | Part # | Description |
|-----|-----------|-------------------------------|
| 1 | D982-0001 | CARBON REAR SPOILER (M2 only) |
| 1 | D982-0010 | CARBON REAR SPOILER (M3 only) |
| 1 | D982-0011 | CARBON REAR SPOILER (M4 only) |

Congratulations for being selective enough to use a DINAN carbon rear spoiler. We have spent many hours developing this kit to assure that you will receive maximum performance and durability with minimum difficulty in installation. Please take the time to read these instructions and call us if you have any difficulties during the installation.

NOTE: This kit does not fit all vehicles configurations. Please pay careful attention to the vehicles listed above. Do not install this kit if your specific vehicle configuration is not shown. Please contact your Dinan representative if you have any questions.



INSTALLATION:

1. Uninstall the OEM trunk spoiler. Using dental floss, slide the strand under one of the edges, and work it back and forth. Once one of the ends come loose, continue to work your way to the other side until the spoiler is removed.
2. Take care to remove any adhesive from the mounting surface. Clean thoroughly afterwards with rubbing alcohol.
3. Test fit the spoiler prior to installing.
4. Align the spoiler on the trunk and mark its proper positioning with painter's tape.
5. Peel the red backing from the 3M tape approximately 2" from either end of the spoiler.
6. Leaving the rest of the 3M tape backing in place, lay the spoiler on the car.
7. Once you have the spoiler in the correct position, carefully remove the red backing of the 3M tape while simultaneously pressing the spoiler firmly into place. It is recommended that two people complete this step.
8. Use painter's tape to apply continuous pressure to hold the spoiler to the trunk after it is installed. Pay extra attention to the corners. It is recommended that you do not drive the car until the spoiler has had sufficient time to cure to the trunklid (an hour is preferred).

NOTE: Proper care will enhance the appearance of your Dinan carbon rear spoiler. Please keep these parts clean and waxed at all times. Like any surface, poor maintenance will allow deterioration to take hold.