



Installation Instructions

D760-0065:

A90 Supra / G29 Z4 (6 CYL)

COLD AIR INTAKE SYSTEM

Document Revision: A

Release Date: December 01, 2022

Thank you for being selective enough to choose a Dinan Performance Intake System. The Dinan Engineering Team has spent many hours developing this product to assure that you will receive increased performance, durability and an aesthetic design that you as a customer will be able to enjoy for many years. Ease of installation and maintenance is important to us and has been highly considered throughout the design process.

Prior to performing the installation, familiarize yourself with these instructions as it should help you with the process. If you feel that you do not have the required skills or tools, please arrange for a qualified repair facility to perform the installation.

If you have any difficulties during the installation, or if these instructions are not clear to you, please call Dinan's Technical Support Staff at (800) 341-5480.


Again, thank you for choosing Dinan. Enjoy.

Table of Contents


PARTS LIST	2
REMOVAL OF STOCK SYSTEM	3
INSTALLATION OF DINAN SYSTEM.....	5

PARTS LIST

ITEM NO.	DINAN Part No	DESCRIPTION	QTY.
1	#36Z	Clamp 9mm, 70-90	2
2	D401-0027	Air Filter	1
3	D671-0143	M4x16x0.7P Button Head, SS	3
4	D671-0147	M4 x 10 x 0.7P Button Head, SS	2
5	D671-0236	Rivet, Push-in Click Lock, Black	5
6	D672-0237	Turbo Inlet Hose	1
7	D762-0292	Airbox Lid, A90	1
8	D762-0294	Intake Tube, A90, 6cyl	1
9	D763-0193	Assy, Lower Airbox, A90, 6-cyl	1
10	M4 NYLOK	M4x0.7P Nylok Nut	3
11	M4X12 FENDER	M4 Washer	6




REMOVAL OF STOCK SYSTEM



STEP 1:

1. Unplug the sensor harness from the airbox
2. Loosen clamp and remove the airbox from the vehicle

Ensure that the rubber mounting grommets from the lower airbox remain in proper location of vehicle.



STEP 2:

Remove clamp on rubber inlet hose in shown location.
*Depending on vehicle, this clamp may need to be cut.

Remove the remaining stock hose from the vehicle

With a cloth, protect the turbo opening so that no debris falls inside.




STEP 3:

Remove the sensor from the airbox.

The sensor will be re-used. The screws will not.

INSTALLATION OF DINAN SYSTEM



STEP 1:

Slide one clamp over the Inlet Hose

Fully seat the Inlet Hose against the stock turbo inlet housing

Tighten clamp

At this time, slide the other clamp onto the top and tighten slightly to hold into place. Final tightening will be completed once the Intake System is installed.



STEP 2:


Using the hardware shown below, mount the inlet tube to the airbox housing and tighten

Screw – Washer – Washer – Nut

6x M4 Washers

3x M4 Lock Nuts

3x M4x16 Bolts



**STEP 3:**

Position the sensor on the inlet tube. This will only fit in one direction.

Use the M4x10 (2) screws and tighten sensor to inlet tube as shown

**STEP 4:**

The filter shall have a supplied clamp in the box


Slide the filter over the tube and proceed to STEP 5

**STEP 5:**

Ensure that the filter is in the correct orientation. The DINAN logo shall be upright when looking at the filter cap.

Double check proper orientation by placing lid on box to ensure the filter does not interfere.

Tighten the Clamp



STEP 6:


Place the assembled intake into the vehicle.

Slide Inlet Tube into Inlet Hose

Snap the airbox into the rubber grommets to fully seat system

The inlet tube shall protrude far enough into hose so that there is plenty of engagement of the clamp

Tighten the Clamp



STEP 7:

Re-attach the sensor and lock



STEP 8:

Using the push rivets (5x), mount the lid to the lower box.

Ensure proper engagement

THE INSTALLATION IS NOW COMPLETE. ENJOY